

Attention: Read This

Read all instructions before installing immersion heaters. Failure to follow the instruction manual provided can result in dangerous operating conditions and potentially create a fire.

- Verify that the voltage on the heater tag matches that of the available power service.
- Make sure that the material of this heater is compatible with the solution to be heated.
- Electric heaters **must** be installed with an appropriate temperature and liquid level control. Always connect the thermal protection devices to these controls as detailed in the instructions.
- Heaters need to be mounted in locations away from contact with work, and the heater heads should be protected from splashing, dripping and excessive moisture. Do not operate electric heaters under covers and always provide adequate ventilation.

Heaters need to be inspected periodically and cleaned when any buildup appears on the surface. This buildup restricts heat transfer leading to higher internal temperatures, increased corrosion, and reduces service life.